



## QUICKSHIP LAB FURNITURE



### WOOD-LEGGED TABLE

The LS wood-legged table is constructed of solid oak and can accommodate up to 2 students per table. The apron is made of solid red oak and attached using heavy-duty 13-gauge steel corner braces. Equipped with non-skid, adjustable glides for precise leveling on uneven floors and black rubber leg boots to protect against scuffing and chemical spills. Variable service supply modules for the integration of all services, from hot & cold water to gas, electricity and data supply lines are also available for this unit. Coordinating accessories and storage options such as reagent shelving and under-bench cabinets, both fixed and mobile, can be selected based on your specific laboratory requirements.

**TABLE SIZES 24" X 54" / 24" X 60" / HEIGHTS 30"H / 36"H**

► [MORE Table Options](#) / [Adjustable Height](#) / [Casters](#) / [Storage](#) / [Service Supply Modules](#)



## QUICKSHIP LAB FURNITURE

### WOOD-LEGGED TABLE

OAK FRAME

THE PERFECT FURNITURE SOLUTION FOR GENERAL SCIENCE, STEM LABS AND ALL MULTI-PURPOSE LABORATORY ENVIRONMENTS.



#### CORNER BRACES

HEAVY DUTY STEEL

13-gauge steel corner braces are screwed into the apron and the leg is held in place with a hanger bolt, nut and lock washer for a tight fit.



#### LEG BOOTS

PREVENT DAMAGE

Our tables come with thick rubber leg boots. These boots protect the legs from water and chemicals used while cleaning the floors.



#### WOOD FINISH

CHEMICAL RESISTANT

Solid red oak wood, smoothly machined and finished with a chemical resistant, non-emitting UV finish.